

Réglages suggérés selon la méthode d'extraction

Aergrind

suggested grinder settings by brew method

First Rotation
Superfine
0:1 – 0:12

Rotation 1+
Fine to Medium
1:0 – 1:12

Rotation 2+
Medium
2:0 – 2:12

Rotation 3+
Medium to Coarse
3:0 – 3:12



Ibrik / Cezve
0:9 – 1:1



Espresso
domestic
1:3 – 1:9
e61 / pro-sumer
1:0 - 1:3



Mokka /
Stovetop
1:3 – 1:9



Aeropress /
Aeropress Go
1:3 – 2:4



V60 /
Kalita Wave
1:8 – 2:8



Filter Machine
2:0 – 2:8



Cafetière
2:8 – 3:8

Chacun prépare son café selon différentes recettes et avec différents cafés. Utilisez donc le schéma d'instructions ci-dessus comme guide de démarrage pour savoir quel réglage de mouture fonctionne pour quelle méthode d'extraction.